

EutroSORB® WC

Water Column Phosphorus Inactivator

KEEP OUT OF REACH OF CHILDREN

Read all FIRST AID and PRODUCT HANDLING directions on label before use.

FIRST AID	
If in eyes:	<ul style="list-style-type: none"> • Hold eye lids open and flush eyes under running water for at least 15 to 20 minutes. • Seek immediate medical attention if irritation persists.
If on skin or clothing:	<ul style="list-style-type: none"> • Remove contaminated clothing. • Immediately rinse skin with water for 15 to 20 minutes. • Seek medical attention if skin irritation persists.
If inhaled:	<ul style="list-style-type: none"> • If exposed to excessive mist in air, move person to fresh air. • Seek medical attention if coughing or respiratory discomfort occurs.
If swallowed:	<ul style="list-style-type: none"> • Rinse mouth with water. • Do not induce vomiting. • Seek medical attention as a precaution.
HOTLINE NUMBER	
Have the product container or label with you when calling a poison control center or doctor or going for treatment. You may also contact INFOTRAC for emergency medical information 1-800-535-5053 .	

PRODUCT INFORMATION:

EutroSORB® WC is a proprietary solution developed specifically for rapid and stable inactivation of phosphorus from the water column of a variety of water bodies such as lakes, reservoirs, ponds, rivers, streams, canals, ditches, etc. EutroSORB® WC is a high performance, water-soluble phosphate binder that does not stain equipment or features.

DIRECTIONS FOR USE

Read all Direction for Use carefully before applying this product, see EutroSORB WC Product Use Guide for additional information. Obtain required permits: Consult with appropriate state or local water authorities before applying the product in or around public waters.

This product can be directly applied to or injected in surface waters and can be used in or around public waters. For best results, distribute EutroSORB WC uniformly over the surface of the water body or the area targeted for phosphorus inactivation. When making applications to flowing waters (e.g., rivers, streams, ditches, etc.), drip or inject EutroSORB WC at a location where adequate mixing occurs to optimize

phosphorus binding. The phosphorus binding of this product will depend on water quality parameters and site-specific conditions.

Please consult a SePRO Technical Specialist for guidance in implementing a treatment program to achieve optimal results. For site specific rate and treatment recommendations, contact your SePRO Technical Specialist or SePRO Corporation at 1-800-419-7779.

PDU Dosage Rate details: Apply 10 PDUs of EutroSORB WC to inactivate 1 lb of phosphorus from the water column.

Storage and Disposal: Store in the original container and keep closed. Store away from and not mixed with oxidizers. Thoroughly rinse the container with treated water before disposal. Offer for recycling if available.

Warranty Disclaimer: SePRO Corporation warrants that testing and research have determined this product is reasonably fit for the uses described on the product label. To the extent consistent with applicable law, SePRO Corporation makes no other express or implied warranty of fitness or merchantability nor any other express or implied warranty and any such warranties are expressly disclaimed.

Misuse: To the extent consistent with applicable law, the buyer assumes responsibility for any adverse consequences if this product is not used according to its label directions. In no case shall SePRO Corporation be liable for any losses or damages resulting from the use, handling or application of this product in a manner inconsistent with its label.

For additional important labeling information regarding SePRO Corporation's Terms and Conditions of Use, Inherent Risks of Use and Limitation of Remedies, please visit <http://seprolabels.com/terms> or scan the image at the below.



EutroSORB is a registered trademark of SePRO Corporation.
© Copyright 2023 SePRO Corporation
FPL20230410

SePRO Corporation 11550 North Meridian Street, Suite 600, Carmel, IN 46032 U.S.A.